


NOTES:

- 1. EDGE TO BE SAWED WITH A CONCRETE SAW TO A NEAT SQUARED EDGE. BROOMED CLEAN OF DUST BEFORE TACK COAT IS APPLIED.
- 2. EDGES TO BE TACKED WITH CRS-I OR CRS-II.
- 3. CONTRACTOR RESPONSIBLE FOR REPLACEMENT OF ANY PAVEMENT MARKINGS DISTURBED OR COVERED BY OVERLAY.

TYPICAL PAVEMENT REPAIRS

NOT TO SCALE



REVISION NO: 1 DATE: AUGUST 2006

STD-WW-11